

Prepping Head & Foot for Ashland Multipoint Lock System & Flushbolts:

SUPPLIES NEEDED: WOOD GLUE & 3/16" DRILL BIT

1. Engage the Ashland Multipoint Lock while the door is open
2. Put wood glue on the tip of the Ashland Multipoint Lock mechanism
3. Push the handle down and the multipoint will go back into the door
4. Then close the door to line up flush with the header.
5. Pull handle up to engage the multipoint lock (keeping door flush with the header) to mark the spot on the head with the glue
6. Then open the door- you will see a straight line of wood glue on the header
7. Using the 3/16" drill bit, put 3 holes on the line- one at each end and one in the middle
8. Then Carefully go back and forth with the drill bit on the line between the holes to open the hole for the Multipoint lock
9. To make hole look clean- make sure the wood on header is straight and that the wood is not angled.
10. Test the Multipoint- Pull the lever up to engage the multipoint. If the handle moves down, then the hole is not clean and the mechanism is hitting something-carefully in small steps make the hole deeper without making the hole bigger.

**** Repeat for the bottom/foot of the door**

**** Double doors- do the same for flushbolts.**

Reach out to your designated DSA sales rep for assistance