

STANDARD ROUGH OPENING SIZES



- For Accoya double doors, add (+) 1/4" to Rough Opening Width.
- For DP-50 double doors (prepped for double bore), add (+) 5/8" to Rough Opening Width -- (+) 7/8" for Accoya.
- Concealed Hinges add (+) 1/2" to each outside jamb prepped for hinges; (E-04 = +1", E-01 = +1/2")

CONFIGURATION	DOOR WIDTH	SIDELITE	R.O. WIDTH		6/8 DOOR	8/0 DOOR	HEIGHT SUBTRACTORS		
					R.O. HEIGHT	R.O. HEIGHT	OUTSWING	DP-50 (In)	ADA (In/Out)
E-01	2/6	N/A	32-1/2"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01	2/8	N/A	34-1/2"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01	3/0	N/A	38-1/2"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01	3/6	N/A	44-1/2"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01B/A	3/0	N/A	38-1/2"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01A	3/6	N/A	44-1/2"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01C	3/0	N/A	39"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01C	3/6	N/A	45-1/4"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04	5/0	N/A	63-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04 <i>Aberdeen W.Iron</i>	5/0	N/A	64-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04	5/4	N/A	67-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04	6/0	N/A	75-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04	7/0	N/A	87-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-17	5/0	N/A	63-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-17 <i>Aberdeen W.Iron</i>	5/0	N/A	64-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-17	5/4	N/A	67-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-17	6/0	N/A	75-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-17B	5/4	N/A	68"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-17B	6/0	N/A	76"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01+SL	2/6	12"	46-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01+SL	2/6	14"	48-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01+SL	2/8	12"	48-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01+SL	2/8	14"	50-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01+SL	3/0	12" (Direct Set)	52-1/8"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01+SL	3/0	12"	52-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01+SL	3/0	14"	54-1/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01+SL	3/6	12" (Direct Set)	58-1/8"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01+SL	3/6	12"	58-1/4"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-01+SL	3/6	14"	60-1/4"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"

- For Accoya double doors, add (+) 1/4" to Rough Opening Width.
- For DP-50 double doors (prepped for double bore), add (+) 5/8" to Rough Opening Width -- (+) 7/8" for Accoya.
- Concealed Hinges add (+) 1/2" to each outside jamb prepped for hinges; (E-04 = +1", E-01 = +1/2")

CONFIGURATION	DOOR WIDTH	SIDELITE	R.O. WIDTH		6/8 DOOR	8/0 DOOR	HEIGHT SUBTRACTORS		
					R.O. HEIGHT	R.O. HEIGHT	OUTSWING	DP-50 (In)	ADA (In/Out)
E-03	2/6	12"	60"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-03	2/6	14"	64"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-03	2/8	12"	62"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-03	2/8	14"	66"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-03	3/0	10"	62"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-03	3/0	12" (Direct Set)	65-3/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-03	3/0	12"	66"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-03	3/0	14"	70"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-03	3/6	12" (Direct Set)	71-3/4"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-03	3/6	12"	72"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-03	3/6	14"	76"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-18	3/0	12"	66"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-18	3/6	14"	76"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-18	3/6	16"	80"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04 + SL	5/0	12" (Direct Set)	90-1/2"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04 + SL	5/0	12"	90-3/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04 + SL	5/0	14"	94-3/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04 + SL	5/4	12" (Direct Set)	94-1/2"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04 + SL	5/4	12"	94-3/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04 + SL	5/4	14"	98-3/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04 + SL	6/0	12" (Direct Set)	102-1/2"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04 + SL	6/0	12"	102-3/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04 + SL	6/0	14"	106-3/4"	x	83-1/2"	99-1/2"	- 5/8"	- 3/8"	- 7/8"
E-04 + SL	7/0	12" (Direct Set)	114-1/2"	x	N/A	99-1/2"	- 5/8"	- 3/8"	- 7/8"

- For Accoya double doors, add (+) 1/4" to Rough Opening Width.
- For DP-50 double doors (prepped for double bore), add (+) 5/8" to Rough Opening Width -- (+) 7/8" for Accoya.
- Concealed Hinges add (+) 1/2" to each outside jamb prepped for hinges; (E-04 = +1", E-01 = +1/2")

CONFIGURATION	UNIT WIDTH	TRANSOM	R.O. WIDTH		6/8 DOOR	8/0 DOOR	HEIGHT SUBTRACTORS		
					R.O. HEIGHT	R.O. HEIGHT	OUTSWING	DP-50 (In)	ADA (In/Out)
E-01 + T	3/0	12" (Direct Set)	38-1/2"	x	96-7/8"	112-7/8"	- 5/8"	- 3/8"	- 7/8"
E-01 + T	3/0	12"	38-1/2"	x	97"	113"	- 5/8"	- 3/8"	- 7/8"
E-01 + T	3/0	14"	38-1/2"	x	99"	115"	- 5/8"	- 3/8"	- 7/8"
E-01 + T	3/0	16"	38-1/2"	x	101"	117"	- 5/8"	- 3/8"	- 7/8"
E-01 + T	3/6	12"	44-1/2"	x	N/A	113"	- 5/8"	- 3/8"	- 7/8"
E-01 + T	3/6	14"	44-1/2"	x	N/A	115"	- 5/8"	- 3/8"	- 7/8"
E-01 + T	3/6	16"	44-1/2"	x	N/A	117"	- 5/8"	- 3/8"	- 7/8"
E-01 + T + SL	12" (D.Set) x 3/0	12" (Direct Set)	52-1/8"	x	96-7/8"	112-7/8"	- 5/8"	- 3/8"	- 7/8"
E-01 + T + SL	12" x 3/0	12"	52-1/4"	x	N/A	113"	- 5/8"	- 3/8"	- 7/8"
E-08	12" x 3/0 x 12"	12"	66"	x	97"	113"	- 5/8"	- 3/8"	- 7/8"
E-08	12" x 3/0 x 12"	14"	66"	x	99"	115"	- 5/8"	- 3/8"	- 7/8"
E-08	12" x 3/0 x 12"	16"	66"	x	101"	117"	- 5/8"	- 3/8"	- 7/8"
E-08	14" x 3/0 x 14"	12"	70"	x	97"	113"	- 5/8"	- 3/8"	- 7/8"
E-08	14" x 3/0 x 14"	14"	70"	x	99"	115"	- 5/8"	- 3/8"	- 7/8"
E-08	14" x 3/0 x 14"	16"	70"	x	101"	117"	- 5/8"	- 3/8"	- 7/8"
E-08	12" x 3/6 x 12"	12"	72"	x	N/A	113"	- 5/8"	- 3/8"	- 7/8"
E-08	12" x 3/6 x 12"	14"	72"	x	N/A	115"	- 5/8"	- 3/8"	- 7/8"
E-08	12" x 3/6 x 12"	16"	72"	x	N/A	117"	- 5/8"	- 3/8"	- 7/8"
E-08	14" x 3/6 x 14"	12"	76"	x	N/A	113"	- 5/8"	- 3/8"	- 7/8"
E-08	14" x 3/6 x 14"	14"	76"	x	N/A	115"	- 5/8"	- 3/8"	- 7/8"
E-08	14" x 3/6 x 14"	16"	76"	x	N/A	117"	- 5/8"	- 3/8"	- 7/8"
E-09	10" x 3/0 x 10"	10"	62"	x	95"	111"	- 5/8"	- 3/8"	- 7/8"
E-09	10" x 3/0 x 10"	12"	62"	x	97"	113"	- 5/8"	- 3/8"	- 7/8"
E-09	12" x 3/0 x 12" (D.Set)	12" (Direct Set)	65-3/4"	x	96-7/8"	112-7/8"	- 5/8"	- 3/8"	- 7/8"
E-09	12" x 3/0 x 12"	10"	66"	x	95"	111"	- 5/8"	- 3/8"	- 7/8"
E-09	12" x 3/0 x 12"	12"	66"	x	97"	113"	- 5/8"	- 3/8"	- 7/8"
E-09	12" x 3/0 x 12"	14"	66"	x	99"	115"	- 5/8"	- 3/8"	- 7/8"
E-09	14" x 3/0 x 14"	10"	70"	x	95"	111"	- 5/8"	- 3/8"	- 7/8"
E-09	14" x 3/0 x 14"	12"	70"	x	97"	113"	- 5/8"	- 3/8"	- 7/8"
E-09	14" x 3/0 x 14"	14"	70"	x	99"	115"	- 5/8"	- 3/8"	- 7/8"

- For Accoya double doors, add (+) 1/4" to Rough Opening Width.
- For DP-50 double doors (prepped for double bore), add (+) 5/8" to Rough Opening Width -- (+) 7/8" for Accoya.
- Concealed Hinges add (+) 1/2" to each outside jamb prepped for hinges; (E-04 = +1", E-01 = +1/2")

CONFIGURATION	UNIT WIDTH	TRANSOM	R.O. WIDTH		6/8 DOOR	8/0 DOOR	HEIGHT SUBTRACTORS		
					R.O. HEIGHT	R.O. HEIGHT	OUTSWING	DP-50 (In)	ADA (In/Out)
E-14	12" x 3/0 x 12"	21"	66"	x	106"	122"	- 5/8"	- 3/8"	- 7/8"
E-14	14" x 3/0 x 14"	21"	70"	x	106"	122"	- 5/8"	- 3/8"	- 7/8"
E-18B	16" x 3/6 x 16"	24"	80"	x	N/A	125"	- 5/8"	- 3/8"	- 7/8"
E-04 + T	6/0	12" (Direct Set)	75-1/4"	x	96-7/8"	112-7/8"	- 5/8"	- 3/8"	- 7/8"
E-04 + T	5/0	12"	63-1/4"	x	97"	113"	- 5/8"	- 3/8"	- 7/8"
E-04 + T	5/4	12"	67-1/4"	x	97"	113"	- 5/8"	- 3/8"	- 7/8"
E-04 + T	6/0	12"	75-1/4"	x	97"	113"	- 5/8"	- 3/8"	- 7/8"
E-04 + SEGT	5/4	21"	67-1/4"	x	106"	122"	- 5/8"	- 3/8"	- 7/8"
E-04 + SEGT	6/0	21"	75-1/4"	x	106"	122"	- 5/8"	- 3/8"	- 7/8"
E-07	5/4	36"	67-1/4"	x	N/A	137"	- 5/8"	- 3/8"	- 7/8"
E-07	6/0	36"	75-1/4"	x	N/A	137"	- 5/8"	- 3/8"	- 7/8"
E-19	5/0	24"	63-1/4"	x	109"	125"	- 5/8"	- 3/8"	- 7/8"
E-19	5/4	24"	67-1/4"	x	109"	125"	- 5/8"	- 3/8"	- 7/8"
E-19	6/0	24"	75-1/4"	x	109"	125"	- 5/8"	- 3/8"	- 7/8"
E-19B	5/0	24"	63-1/4"	x	N/A	125"	- 5/8"	- 3/8"	- 7/8"
E-19B	5/4	24"	67-1/4"	x	N/A	125"	- 5/8"	- 3/8"	- 7/8"
E-19B	6/0	24"	75-1/4"	x	N/A	125"	- 5/8"	- 3/8"	- 7/8"