

Handling and Storage Do's and Don'ts:

1. Deliver doors in a clean truck and under cover.
2. Do not deliver or install doors until foundations, concrete floors and plaster or texture walls are completely dry.
3. Leave all the wrapping on the door until you are ready to take it out and finish it OR install it
4. Allow doors time to acclimate to the conditions at the job site prior to installation.
5. Never subject doors to abnormal heat, dryness or humidity for prolonged periods (i.e. forced heat).
6. **Store doors lying flat** on a level surface above the ground in a dry, well ventilated building and keep covered. Don't stack doors on end. Never store leaning straight up against a wall, it will bow the wood
7. Doors must be stored indoors or in a weather protected environment.
8. If the doors are to be stored on the job site, the entire door, including top and bottom edges, must be sealed with a clear or pigmented based sealer to prevent moisture absorption. All six sides of the door must be properly sealed for warranty to apply.
9. To keep doors protected, use clean gloves and equipment. Cover doors, but allow for air circulation. Carry, do not drag doors over any surface.

Important Note: Panels of stile and rail doors are engineered to float so they can move with changes in climate without causing stress. Make sure these components are aligned before finishing. You can correct alignment by carefully moving the panel with a wood block, rubber mallet and a soft touch. Components that have shifted and must be aligned are not considered "defects" according to the warranty.

***Mishandling and/or storing improperly a DSA door could void your DSA Warranty**