



ROUGH OPENING SIZES

Door Configuration	R.O. Size
E-01	
2/6 x 6/8	32 1/2" x 83 1/2"
2/8 x 6/8	34 1/2" x 83 1/2"
3/0 x 6/8	38 1/2" x 83 1/2"
3/0 x 7/0	38 1/2" x 87 1/2"
2/6 x 8/0	32 1/2" x 99 1/2"
2/8 x 8/0	34 1/2" x 99 1/2"
3/0 x 8/0	38 1/2" x 99 1/2"
3/6 x 8/0	44 1/2" x 99 1/2"
E-01B	
3/0 x 8/0	38 1/2" x 99 1/2"
3/0 x 8/0-halfround	39" x 99 1/2"
3/6 x 8/0	44 1/2" x 99 1/2"
E-03	
1/0 - 3/0 - 1/0 x 6/8	66" x 83 1/2"
1/0 - 3/0 - 1/0 x 7/0	66" x 87 1/2"
1/2 - 3/0 - 1/2 x 6/8	70" x 83 1/2"
1/2 - 3/0 - 1/2 x 7/0	70" x 87 1/2"
1/0 - 3/0 - 1/0 x 8/0	66" x 99 1/2"
1/2 - 3/0 - 1/2 x 8/0	70" x 99 1/2"
1/0 - 3/6 - 1/0 x 8/0	72" x 99 1/2"
1/2 - 3/6 - 1/2 x 8/0	76" x 99 1/2"
1/4 - 3/6 - 1/4 x 8/0	80" x 99 1/2"
E-04 with and without iron	
5/0 x 6/8	63 1/2" x 83 1/2"
5/4 x 6/8	67 1/2" x 83 1/2"
6/0 x 6/8	75 1/2" x 83 1/2"
5/0 x 8/0	63 1/2" x 99 1/2"
5/4 x 8/0	67 1/2" x 99 1/2"
6/0 x 8/0	75 1/2" x 99 1/2"
E-07	
5/4 x 8/0 with 3/0 arch transom	67 1/2" x 137"
6/0 x 8/0 with 3/0 arch transom	75 1/2" x 137"
E-08	
1/0 - 3/0 - 1/0 x 6/8 with 1/0 transom	66" x 97"
1/0 - 3/0 - 1/0 x 7/0 with 1/0 transom	66" x 101"
1/2 - 3/0 - 1/2 x 6/8 with 1/0 transom	70" x 97"
1/2 - 3/0 - 1/2 x 7/0 with 1/0 transom	70" x 101"
1/0 - 3/0 - 1/0 x 6/8 with 1/2 transom	66" x 99"
1/0 - 3/0 - 1/0 x 7/0 with 1/2 transom	66" x 103"
1/2 - 3/0 - 1/2 x 6/8 with 1/2 transom	70" x 99"
1/2 - 3/0 - 1/2 x 7/0 with 1/2 transom	70" x 103"
1/0 - 3/0 - 1/0 x 6/8 with 1/4 transom	66" x 101"
1/0 - 3/0 - 1/0 x 7/0 with 1/4 transom	66" x 105"
1/2 - 3/0 - 1/2 x 6/8 with 1/4 transom	70" x 101"
1/2 - 3/0 - 1/2 x 7/0 with 1/4 transom	70" x 105"
E-09	
1/0 - 3/0 - 1/0 x 6/8 with 1/0 transom	66" x 97"
1/2 - 3/0 - 1/2 x 6/8 with 1/0 transom	70" x 97"
1/0 - 3/0 - 1/0 x 8/0 with 1/0 transom	66" x 113"
1/2 - 3/0 - 1/2 x 8/0 with 1/0 transom	70" x 113"
1/0 - 3/0 - 1/0 x 6/8 with 1/2 transom	66" x 99"
1/2 - 3/0 - 1/2 x 6/8 with 1/2 transom	70" x 99"
1/0 - 3/0 - 1/0 x 8/0 with 1/2 transom	66" x 115"
1/2 - 3/0 - 1/2 x 8/0 with 1/2 transom	70" x 115"

Door Configuration	R.O. Size
E-12	
1/0 - 3/0 - 1/0 x 6/8 with half round transom	65 1/2" x 116 7/8"
1/2 - 3/0 - 1/2 x 6/8 with half round transom	69 1/2" x 118 7/8"
1/0 - 3/0 - 1/0 x 8/0 with half round transom	65 1/2" x 132 7/8"
1/2 - 3/0 - 1/2 x 8/0 with half round transom	69 1/2" x 134 7/8"
E-14	
1/0 - 3/0 - 1/0 x 6/8 with segment arch transom	66" x 106"
1/2 - 3/0 - 1/2 x 6/8 with segment arch transom	70" x 106"
1/0 - 3/0 - 1/0 x 8/0 with segment arch transom	66" x 122"
1/2 - 3/0 - 1/2 x 8/0 with segment arch transom	70" x 122"
E-17 with and without iron	
5/0 x 6/8	63 1/2" x 83 1/2"
5/4 x 6/8	67 1/2" x 83 1/2"
6/0 x 6/8	75 1/2" x 83 1/2"
5/0 x 8/0	63 1/2" x 99 1/2"
5/4 x 8/0	67 1/2" x 99 1/2"
6/0 x 8/0	75 1/2" x 99 1/2"
E-17B	
5/4 x 8/0	67 1/2" x 99 1/2"
6/0 x 8/0-halfround	68" x 99 1/2"
6/0 x 8/0	75 1/2" x 99 1/2"
6/0 x 8/0-halfround	76" x 99 1/2"
E-18	
1/0-3/0-1/0 x 8/0	66" x 99 1/2"
1/2 - 3/6 - 1/2 x 8/0	76" x 99 1/2"
1/4 - 3/6 - 1/4 x 8/0	80" x 99 1/2"
E-18B	
1/4 - 3/6 - 1/4 x 8/0 with 2/0 arch transom	80" x 125"
E-19 & E-19B (2/0 transom)	
5/0 x 8/0 (5/0 not available with iron)	63 1/2" x 125"
5/4 x 8/0	67 1/2" x 125"
6/0 x 8/0	75 1/2" x 125"

NOTES

ADD a 1/2" width to double DP Rated doors with double bore

All heights trimable down 3 1/2"

*except halfround doors

ADA Sills subtract 7/8" from height

Single Door with 1 sidelight:

Formula: E-04 (RO width)- 1 1/2" (mullspace) - (1 sidelight size)

Example: 3/0x1/0 66"-1 1/2" = 64-1/2"-12" = 52-1/2"

Double Door with 2 sidelights:

Formula: E-04 (RO width)+3" (mullspace) + (sidelight widthx2)

Example: 1/0x6/0x1/0 75 -1/2" +3" = 78 -1/2" +24" = 102-1/2"